

# LabJack

Published on *LabJack* (<https://labjack.com>)

[Home](#) > PS12DC Power Switching Board

---

## PS12DC Power Switching Board

Controlled through 12 digital outputs, the PS12DC can switch power sources ranging from 5 to 28V DC. Attach the PS12DC to the DB15 connector presented on all compatible devices, and toggle the states of the EIO and CIO digital output lines to turn the switches on/off. Designed for medium to low current DC power switching applications.

- 12 digitally controlled switches with LED indicators
- Optical isolation
- Handles 5 - 28 Volt supply
- Up to 750mA/ch
- Thermal (self-resetting) fuse protection
- Flyback protection

For more information, reference the [datasheet](#).

Information

**Stock Status:** In Stock

**Compatible Products:**

[U3](#)

[T7](#)

[U6](#)

[UE9](#)

[T4](#)

\$109.00

Quantity Discounts:

1 - 9 = \$109.00 per unit

10 - 29 = \$100.28 per unit

30+ = \$93.74 per unit

**Quantity**

Add to cart

---