

LabJack

Published on *LabJack* (<https://labjack.com>)

[Home](#) > [Digit \(Discontinued\)](#)

Digit (Discontinued)

Digit-TL

End Of Life Notification (November 2017)

New Digit production is discontinued and the Digit is not recommended for new customers. Previous Digit users [contact us](#) about availability.

Notice: A new version of [Otero \(v1.56\)](#) and [Digit firmware \(v1.23\)](#) was released 11/10/2017. It is recommended that all digit customers using a compatible hardware version of the Digit update to the latest versions of each. Otero is installed by installing the latest release version of our installation package. The binary (.bin) firmware file is available at the bottom of the [digit firmware](#) page. Open Otero and follow the [update firmware](#) section on the [Otero application](#) page to upload the .bin file to the Digit.

The Digit-TL logs temperature and approximate light.

Digit-TL

Add Aluminum Enclosure

No

Quantity

\$39.99

Quantity Discounts:

1 - 9 = \$39.99 per unit

10 - 29 = \$37.99 per unit

30+ = \$35.99 per unit

 [Digit-TL Product Brief](#)

Stock Status: In Stock

ETA: Discontinued

Battery powered data logger

Battery powered data logger

The Digit series collects data in a remote location, and stores it to internal memory. When finished, the data can be downloaded via the convenient USB connector. Traditional applications include shipping, weather monitoring, agriculture, and refrigeration. The miniature size makes it convenient for logging temperature on-the-go.

Every data point is given a timestamp, so it is possible to see when temperature changes occur, and with 7 different log intervals, it is easy to customize how frequently data points are collected. Use the 2 programmable LED alarm thresholds to detect if temperatures exceeded permissible boundaries, such as in a refrigerator. One unique feature to this data logger is the included approximate ambient light sensor.

An optional aluminum enclosure can be purchased if the device needs to be submerged in water for extended periods of time. The aluminum enclosure does not let any light into the case so the light readings will always report it being "dark".

This device supports Windows XP, Vista, 7, 8, 8.1, and 10. The UI program called Otero is not available for Mac OS X and Linux based operating systems.

▶ [Hardware Overview](#)

▶ [Other Highlights](#)

▶ [Accessories](#)

Support Resources

▶ [Getting Started](#)

▶ [Datasheet and Application Notes](#)

▶ [Contact Us](#)
